


ODYSSEY 200

Three action-packed games
All with Electronic On-Screen Scoring

**WORKS ON ANY BRAND...
ANY SIZE TV...
COLOR or BLACK & WHITE**


In 1972 Magnavox introduced Odyssey — the first home video game. Since then, Odyssey has gained national and international reputation and acclaim. It truly makes a TV more than something to just sit and watch! It turns the TV screen into an electronic playground that challenges the skill and coordination of the players. Now, there's all new Odyssey 200 and 100 (see back cover) — with more simplified set up, ease of operation . . . and with fewer parts for greater reliability. Odyssey is a game for the entire family — for all ages. Come in for a demonstration. You'll know why we say, "Odyssey . . . is America's most exciting home video game".



TENNIS

HOCKEY

SMASH



With three action-packed games for the entire family . . . Tennis, Hockey and Smash . . . deluxe Odyssey 200 (Model YF 7015) offers the following features for convenient and exciting playing:

Electronic On-Screen Scoring. Two visual index bar displays move through 15 different positions, one at a time, as each player scores.

Mechanical Scoring. An indicator on the Master Control gives added score-keeping capability.

Action Sound. Each time the ball hits a player or wall, an electronic sound is activated. If desired, the sound may be deactivated.

Ball Rebound from top and bottom of the screen, gives greater interest and excitement to each game.

Vertical and Horizontal Player Action. The Master Control has two sets of rotary controls to move the players on the screen.

Ball Control. Each player has a rotary control to put "English" on the ball to out-manuever his opponent.

Speed Control enables players to set the pace of the game and allows them to play at the level of their ability. It also helps improve reaction timing and skill.

Game Select Switch on Master Control Center permits quick selection of Tennis, Hockey or Smash.

Two/Four Player Switch permits playing doubles at Tennis and the challenge of a goalie while playing Hockey.

Center Control to adapt Odyssey to all television receivers.

On/Off Power Switch activates the game you select.

Odyssey operates on 6 "C" batteries (not included) or on an optional (at extra cost) AC adaptor.